

# SCROLL COMPRESSOR TECHNICAL DATASHEET: YM49E7G-100



Basic Specification	bn		
Model	YM49E7G-100		
Widei	(Including Extended Models)		
Туре	Low Side Shell Design Scroll		
1360	Compressor		
Application	Medium Temp. Refrigeration		
Refrigerant	R448A / R449A		
Power	3 HP		
Capacity (BTU/Hr)	20520		
Displacement(cc/rev)	46.6		
Cooling Capacity(W) <sup>(a)</sup>	6014		
Input Power(W) <sup>(a)</sup>	2791		
RLA(A) <sup>(a)</sup>	9.5		
Cooling COP(W/W) <sup>(a)</sup>	2.15		
Power Supply	208-230V/3~/60Hz		
Min. Operating Voltage(V)	187		
Max. Operating Voltage(V)	253		
LRA(A)	88		
Max. Operating Current(A) <sup>(b)</sup>	14.1		
Rated Speed(r/min) <sup>(a)</sup>	3500		
Compressor Weight (With Oil)(kg)	30		
Oil Type	POE		
Oil Kinematic Viscosity(cSt, 40°C)	32		
Oil Density(kg/L, 20°C)	0.977		
Primary Charge(L)	1.4		
Recharge(L)	1.25		
Oil Circulation Rate <sup>(a)</sup>	≤1%		
Rated Sound(Sound Power)(dBA)(c)	73		
Max. Operating Sound in Running Envelope	78		
	0.00		
Vibration Displacement Peak-Peak(mm)	≤0.09		
Moisture(mg)	≤500		
Impurity(mg)	≤100		
LVS(V) <sup>(e)</sup>	177		
MOV (V) <sup>(f)</sup>	187		
Start Capacitor(µF/V)	/		
Start Relay	/		
Run Capacitor(µF/V)	/		
IP Class of Terminal Box	IP21		
Compressor Color	Black		

Motor	Falameleis
Motor Type	Three-phase asynchronous motor
Motor Pole	2
Motor Insulation Class(°C)	130(B Class)
Line to Line Resistance $UV(CS)(\Omega, 25^{\circ}C)$	1.006( ± 10%)
Line to Line Resistance UW(CR)( $\Omega$ , 25°C)	1.012( ± 10%)
Line to Line Resistance VW(SR)( $\Omega$ , 25°C)	0.992( ± 10%)
Dielectric Strength	2000VAC / 1s / 60Hz, Leakage Current≤5mA
Insulation Resistance(M $\Omega$ )	≥20
Ground Resistance( $\Omega$ )	≤0.1
Safety O	perating Limit
Safety O Tightness Test Pressure (MPa)	perating Limit 3.8-4.0
Safety O Tightness Test Pressure (MPa) Max. Ope	perating Limit 3.8-4.0 rating Pressure
Safety O Tightness Test Pressure (MPa) Max. Ope High Side(MPa) Low Side(MPa)	perating Limit 3.8-4.0 rating Pressure H3.2/L2.0
Safety O Tightness Test Pressure (MPa) Max. Ope High Side(MPa) Low Side(MPa) Compressor Fre	perating Limit 3.8-4.0 rating Pressure H3.2/L2.0 eeSpace(Without Oil)
Safety O Tightness Test Pressure (MPa) Max. Ope High Side(MPa) Low Side(MPa) Compressor Fro High Side(L) Low Side(L)	perating Limit 3.8-4.0 rating Pressure H3.2/L2.0 eeSpace(Without Oil) H1.0/L3.8
Safety O Tightness Test Pressure (MPa) Max. Ope High Side(MPa) Low Side(MPa) Compressor Fr High Side(L) Low Side(L) Max. Refrigerant Charge(kg)	perating Limit 3.8-4.0 rating Pressure H3.2/L2.0 eeSpace(Without Oil) H1.0/L3.8 See Notes
Safety O Tightness Test Pressure (MPa) Max. Ope High Side(MPa) Low Side(MPa) Compressor Fro High Side(L) Low Side(L) Max. Refrigerant Charge(kg) Discharge Temperature Limit(°C)	perating Limit   3.8-4.0   rating Pressure   H3.2/L2.0   eeSpace(Without Oil)   H1.0/L3.8   See Notes   ≤125   (120mm to compressor discharge connection and well insulated)

Performance Condition:

Condition	Condition Description
а	Rated Condition
b	Max. Load Condition, 90% Rated Voltage
С	Rated Condition, A Weighted Sound Power
d	Rated Condition, Max Operating Normal Displacement of Compressor Housing
е	Discharge Pressure and Suction Pressure: Saturated Refrigerant Pressure at 40°C
f	Max. Load Condition

2. Rated Condition, 48 Hours Break-in-Running before implementing Performance and Sound Testing

Item	Rated Condition	Max. Load Condition
E.T.(°C)/C.T.(°C)/S.H.(K)/ S.C.(K)/ A.T.(°C)	-6.7/48.9/11.1/0/35	10/65/11.9/0/46.1
Cooling Capacity Deviation	≥92.5%	-
Power Deviation	≤107.5%	-
COP Deviation	≥92.5%	-

### 3. Internal Protector

Protection Method	Config	Parameter				
	With	Vendor	Vendor 1	Vendor 2		
Internal Overload Protector		Model	37HM408-XX			
		Open Temp.(°C)	125±5			
		Close Temp. (°C)	60±9			
		Short Time Trip	64A	А		
		Short time trip	2-10s	S		
Internal Pressure Relieve Valve	With	2.76-3.10MPa				

### 4. Accessory

ltem	Name	P.N.	PCS
1	Grommet	070-0003-00	4
2	Sleeve	010-0014-00	4

## 5. Compressor Operating Envelope



Compressor Performance Sheet

- Performance Based on Superheat is within the Operating Envelope, Subcooling after Condenser is 0K;
- » Performance Calculated by Coefficients of Polynomial is Only Suitable for the Condition within Operating Envelope
- » Capacity, Power can be Calculated by Coefficients of Polynomial





## SCROLL COMPRESSOR TECHNICAL DATASHEET: YM49E7G-100



Performance Table										
Item	E.T.(°C) C.T.(°C)	-30	-25	-20	-15	-10	-5	0	5	10
	65					4153	4982	5979	7170	8580
	60				3735	4519	5455	6570	7888	9435
	55			3278	4016	4891	5927	7152	8591	10269
	50		2801	3492	4304	5262	6393	7722	9276	11079
Cooling	45	2325	2967	3715	4595	5630	6849	8276	9937	11858
Can AAA	40	2462	3145	3944	4883	5990	7290	8808	10571	12604
Cap. (W)	35	2612	3329	4172	5166	6338	7712	9315	11173	13311
	30	2771	3516	4397	5439	6668	8111	9793	11739	13976
	25	2935	3701	4613	5697	6978	8482	10236	12264	
	20	3099	3880	4817	5935	7262	8821	10640		
	10	3412	4202	5169	6338	7735				
	65					3462	3699	3876	4003	4092
	60				2992	3237	3422	3557	3654	3722
	55			2567	2817	3007	3149	3251	3326	3384
	50		2183	2437	2631	2776	2883	2962	3024	3081
Power (W)	45	1840	2095	2291	2438	2546	2628	2692	2751	2815
	40	1790	1985	2131	2240	2321	2386	2445	2509	2589
	35	1711	1855	1961	2040	2103	2161	2224	2302	2408
	30	1607	1709	1784	1843	1897	1956	2031	2133	2273
	25	1481	1549	1602	1650	1704	1773	1870	2005	
	20	1335	1380	1420	1465	1528	1617	1744		
	10	999	1023	1063	1132	1239				

Ten Coefficients of Polynomial							
Expression	z = p0 + p1*x + p2*y + p3*x^2 + p4*x*y + p5*y^2 + p6*x^3 + p7*x^2*y + p8*x*y^2 + p9*y^3						
Description	z:Cooling Capacity(W) or Power (W) Specially: Heating Capacity(W)=Cooling Capacity(W)+Power (W) x: E.T. °C y: C.T. °C 0~p9: Coefficients of Polynomial						
Cooling Cap. Factor	Value Power Value Factor Value						
p0	11786.999	p0	1652.883147				
p1	434.937524 p1 76.870181						
p2	-35.545384 p2 -13.958497						
р3	6.514005 p3 1.84632						
p4	-1.657572 p4 -3.065844						
p5	-1.20541	p5	1.009231				
p6	0.034398 p6 0.014277						
p7	-0.04065 p7 -0.043665						
p8	-0.025872 p8 0.036091						
p9	0.005809 p9 -0.004128						

## Grommet Drawing



9

94

#### Sleeve Drawing



ATED STEEL PIPE: KNESS: 0.0025-0.0070mm, KNESS:1.1-1.3MM;



#### Notes

- It is not allowed to perform vacuum in the system by using the refrigeration compressor. The » compressor can start only after the refrigerant charged. In some cases, such as on the field site, if it is limited by the situation that can't charge the required volume of refrigerant, 50% of the required refrigerant is charged necessary before the compressor starts. Double check the system and make sure everything is under safe status, then power on the compressor and charge the remained refrigerant when the compressor is running.
- It is not allowed to charge the refrigerant from the suction or discharge line closes to the compressor. The charge port should be arranged on the connection pipe of suction line accumulator or receiver, which is on the side far away to the compressor, to avoid the liquid refrigerant flood back.
- Refrigerant charge limitation: the ratio between the weight of oil and refrigerant should be » >=0.4
- It is not allowed to vacuum by compressor, not allowed to run the compressor without refrigerant, and not allowed to run the compressor on the reversed direction for long duration. The compressor can only work with approved refrigerant.
- The compressor is not allowed to work outside its envelope, the system should guarantee the
- suction line superheat and avoid the liquid refrigerant flood back. When the suction and discharge plugs are removed, the assembly and brazing should be done in 15 minutes
- The frequently start/stop should be avoided. The suggested minimum continuous running time is 10 minutes to guarantee the safe oil level (>=50% initial charge volume), the suggested minimum interval duration between start and stop is 3 minutes.
- The deviation of supplied voltage should be less than +/-10% of rated voltage.
- A 70W crankcase heater is recommended to avoid the refrigerant migration during the off circle and flood start. The crankcase heater should be power on 12 hours earlier than the first
- start or restart after long duration off. The system should be equipped with necessary protection devices, such as pressure,
- temperature, oil return, overcurrent and phase fault, etc.
- The compressor is not allowed to lay down or place upside down during transportation, stock and installation. The maximum inclination is 15° when the compressor is running.



Application

» See Details in the YM serial MBP refrigerant scroll compressor application manual

www.invotechnico.com.mx MEXICO: +52 (81) 1306 8037 / info@invotech-mx.com www.invotechnico.com USA: (713) 681-0685 / info@invotech-usa.com